



BLACK PEARL - System Information

Black Pearl Primer Adhesive
Apply 15-20 mils of Black Pearl® Primer Adhesive with a non-serrated straight edge squeegee at the rate of 45 sq. ft./gal. Allow it to dry to a tacky condition (approximately 20 minutes) before installing the Black Pearl® Sheet Membrane.

Black Pearl Primer Adhesive
Black Pearl Sheet Membrane
Rub the sheet into the Black Pearl® Primer Adhesive with a stiff broom, squeegee, hand garden roller, or similar method. Lap all edge seams a minimum of 3 inches. Stagger all end laps a minimum of 6 inches. Coat the top of the first ply with 15-20 mils of Black Pearl® Primer Adhesive at the rate of 45 sq.ft./gal. Allow to dry to tack state.

Black Pearl Primer Adhesive
Black Pearl Sheet Membrane
Smoothly embed the second ply, offsetting the side laps of the first ply by half a sheet's width. Any "Fishmouths" or wrinkles in the fabric need to be cut out and detailed.

RT250 - Additional Product Information and Components

Black Pearl Primer Adhesive

Black Pearl Butyle Tape

Ram Protection Course (Ram 203,306,306FR)
Non-Granulated (non-exposed)
Granulated (exposed)

BUTYL OR POLYURETHANE SEALANT
Ram Mastic, Keene Seal or Liquid Flash 100

RamDrain Drainage Mat

Barrett

THE BARRETT COMPANY

www.BarrettRoofs.com
1-800-647-0100

DRAWN BY: LDS	SYSTEM: BLACK PEARL
DATE: 12.02.2024	CATAGORY: EJ
DETAIL NAME: EXPANSION JOINT IN DECK	DETAIL #: BP-EJ-02